

NOURISHING STYLER

UK > CLEANING & MAINTENANCE GUIDE

We recommend that you clean the styler around every 2-3 uses, and also when the styler has not been used in 5 days, or every time the Keratin Fuel needs to be refilled. Clean it by adding clean water in the tank and letting the water flow through the system, by pressing the vacuum button.

After cleaning, empty out any remaining water and refill the styler with Keratin Fuel.



We also recommend cleaning the plates of the styler with either ethanol or alcohol. This both cleans the surface and removes eventual residues of the Keratin Fuel to avoid clogging up the holes in the plates.

Please note: The styler is not waterproof. A small amount of alcohol will not damage the styler but avoid getting fluids into the housing of the tool.

hh simonsen®

NOURISHING STYLER

DK > RENGØRING & VEDLIGEHOLDELSSES GUIDE



Vi anbefaler at du rengør din styler efter ca. hvert 2-3. gang, eller hvis ikke din styler har været i brug i cirka 5 dage, eller hver gang du genopfylder den med Keratin Fuel. Rens den ved at fylde tanken med rent vand og lad det køre gennem systemet ved at trykke på vakuum-knappen.

Efter rengøring, tømmes styleren for overskydende vand og genopfyldes med Keratin Fuel.

Vi anbefaler også at rengøre stylerens plader med enten etanol eller alkohol. Dette renser både overfladerne og fjerner eventuelle rester af Keratin Fuel, for at undgå at hullerne i pladerne bliver tilstoppede.

Bemærk venligst: Styleren er ikke vandtæt. En lille smule alkohol til rengøring skader ikke styleren, men undgå at få væsker ind i selve styleren.

hh simonsen®